



Attention: All Absolute Ozone® generators are designed to work without service, maintenance, or spare parts for the first 20 years of use if they are installed correctly.

"For good generator performance, it is important to place the generator in a well-ventilated, dust-free environment, and maintain the ambient temperature at 20-22°C."